DIGITAL HOUR METER COUNTER

Cat. No.: Z2301N0G1FT00 Z2221N0G2FT00




FEATURES:


- Suitable for Hour meter & Counter (Up / Down) application
 Wide Hour meter range from 1 sec to 9999999 hrs.

- Wide counter range from 1 to 9999999 counts.
 Prescaling facility for Counter.
 Alarm facility for both Hour meter & Counter.
- MOSFET Output with Over Load detection.
 Retentive & Non-Retentive modes.
- 7 Digit LCD with luxurious green backlight.
 Password protection for device setting.
- Compact size with panel mounting facility.

CONNECTION DIAGRAM:




Proximity Switch Connection Diagram:




NOTE: In PNP & NPN proximity switch connection diagram mention wire color (Brown, Blue & Black) as per required connection for your reference only.


Using MOSFET O/P as signal I/P to External system



Product Catalog Number		Z2301N0G1	FT00	Z2221	N0G2FT00		
Supply Characteristics :							
Supply Voltage Range (Un)		9 to 30 VDC		85 to 265	VAC/VDC		
Power Consumption		2 W max.		2VA / 1W			
Supply Frequency			50/60 Hz				
I/P Sigr	nal Ch	naracteristics :					
Signal Volt		nge	9 to 30 VDC		85 to 265	VAC & 100 to 265 VDC	
Signal Isola		cteristics :	2kv				
Output Characteristics : Output type			2MOSFET:30 VD Note:Use isolate		5 A(Res.)	N/O, Contact Rating:)@250 VAC/30VDC Material: Ag Alloy	
Function	nal Ch	naracteristics:				, , , , , , , , , , , , , , , , , , ,	
Display			7 digit LCD , 6.5 mm Height, 12 O' Clock, Transmissive				
Number of		In	2 (SET key & R			1	
Reset fund	tion	Reset type Time(minimum)	Terminal 80 ms		ont Sec	Auto Reset	
Hour	Accur	<u> </u>	+/- 2 Sec per c		-		
Meter		•	Hrs : Min : Sec	(999:59:59),	Hrs : Min	(99999:59),	
Functions	Range		Hrs (9999999),				
		Signal	Refer Note1				
	Accura		100 % 1 to 9999999.99	19 (may 7 digit	c are vicih	اما	
Counter	Range	al Point Position(max.)	3	19 (Illax. / ulgit	s are visib	ile)	
Functions	Pre-sc		4-Digit				
	Input	Switching Freq.(max.)	10 Hz for AC and	d 40 Hz for DC			
	Signal	Pulse Width min.		50ms ON/50ms OFF for AC, 12.5ms ON/12.5ms OFF for DC			
Enviror		tal Characteristic	·	-,	- /-		
Operating '			-5° C to +55° C				
Storage Te			-10° C to +60° C				
Humidity			5 to 95% Rh (Without condensation)				
		ng Altitude	2000 m				
Pollution D Degree of I		ion	II				
Enclosure i			Front side: IP40; Terminals: IP20, Housing: IP30 UL 94 V0 Plastic				
Casing cold			Black				
Other C	hara	cteristics :					
Mounting			Flush mounting	on panel cut-ou	t		
Panel Cut-		1)	22mm X 44.8mm				
Weight (Ur Operating			52 gm				
Termination			Horizontal Wire size : 22-14	4 AWG, 0.3-2.5	mm		
		ompliance:		, 2.0			
Harmonic (Current	: Emissions	IEC 61000-3-2	Class A			
	cker &	Fluctuation	IEC 61000-3-3	Class A			
ESD Padiated S	IICCCD+:	hility	IEC 61000-4-2 IEC 61000-4-3	Level II Criter	ria B		
Radiated S Electrical F		nsients(Supply)	IEC 61000-4-3	Level IV	10 D		
		nsients(Signal)		Level III			
Surge			IEC 61000-4-5	Level III			
Conducted Susceptibility		IEC 61000-4-6	Level III				
Power Frequency Magnetic Field		IEC 61000-4-8	Class 4				
Voltage Dips		IEC 61000-4-29					
Conducted Emission Radiated Emission		CISPR 11 CISPR 11	Class A Class A				
Safety Compliance:							
		erminal to housing)	UL 508	1.5 kV			
Single fault		IEC 61010-1					
Leakage Current		UL 508	<3.5 mA				
Environmental Compliance:							
Cold Heat		IEC 60068-2-1					
Dry Heat		IEC 60068-2-2					
Vibration			IEC 60068-2-6	5 g			
Repetitive Shock		IEC 60068-2-27					
Non-repetitive Shock			IEC 60068-2-27	30 g, 15 ms			

Overall Product Dimensions & Mounting Details (in mm)





RET FONCTIONS & DETECTION TIME :			B - Hour C - Minute	
	Key	Edit mode & Detection Time	Run mode & Detection Time	D - Second
	SET	To save or shift to next digit 50 ms Minimum.	O/P OFF in Hour Mode O/P OFF in Latch mode of Counter As ACK - 2 sec Minimum. E - Alarm F - Count G - Hour	
			Quick EDIT mode entry>= 5 sec	Symbol H - RESET(RST)
	RESET	To edit Parameter value 50 ms Minimum.	To reset count if front reset is enabled. Reset functionality>= 2sec	I - SET

FREQUENTLY ASKED QUESTIONS:

Q1. How can I change the device mode from Counter to Hour Meter or vice versa? **Ans:** To change the device mode from counter to hour meter or vice versa , it is required to reset the device, then in edit mode select the respective mode.

Q2. How to Reset the Counter/Hour meter, if 'Reset' is disabled?

Ans: If user disables Reset and save the setting, after that again user enables reset then only Terminal reset option is available to user. User has to enable the terminal reset, then reset the device count/time by shorting terminal reset pin & common ground pin. After this only user will see all reset settings in Edit menu.

Q3. What should I do when device flashes the Roll over message?

Ans: This means, device display limit is rolled over, then reset the count/time or change the resolution. rol Our


Q4. What should I do when device flashes the Over load message?

Ans: This means, that two MOSFET output device is over loaded. In output ON condition, when over load condition is occurs then "ol. ALARTI" or "ol. oFSEE" is displayed in two MOSFET device only, output is turned OFF. Press set key for >=2 sec to see the normal screen & make sure that connected load current should not be greater than 60mA. When both output are ON and both at over load condition then "oL both" screen will display.



NOTE 1. For Hour counting detection, Signal has to be present for minimum 3msec and absent for minimum 20msec. e.g. 1. If the signal has 5 msec ON & 30 msec OFF, 5 msec time will keep on accumulating for every pulse. 30 msec off period will be considered as zero. 2. If signal has 3 msec ON time & 17 msec off time, then this full period (3+17=20) msec) will be treated as signal present and time will be calculated for full period of signal presence.

Optional Accessory: ZF1907P: This is the Adapter plate suitable for mounting the Digital counter Hour meter, in panel cutout of 50mm x 25mm with counter sunk M4 screw fitting with vertical center to center distance of 38.2mm.



Quick access for Alarm & Offset preset value edit:

- Press "SET" key for >=5sec.
- 1. Press "SEI" key for >= SSEC.
 2. If ALARM is disabled then device will show "ALARM N" and back to RUN mode (Home screen). Refer Scr 71
- 3. If ALARM is enabled then device will show first "ALARM Y" and then show
- 3. If ALARM is enabled then device will snow first "ALARM Y" and then snow the current Preset value (eg. 000:00:10). Refer Scr 72

 4. After that, by using SET and RESET key user can set Alarm preset value.

 5. After setting the alarm value, if the device is two MOSFET and hour meter is set then according to offset y/n setting, 'Offset Y' or 'Offset N' screen will be displayed for 500 msec and then the offset value will be displayed for edit, otherwise, alarm value will be saved and device will come out of EDIT mode and goes to RUN mode.
 6. After setting the offset value the device will save these two values and come out of
- edit mode and goes to Run mode.



Mode selection:

Set Hour meter mode as per required resolution. Refer (Scr 3 to Scr 7). If the resolution is changed in RUN mode then hour meter shows time change as per selected mode.

Alarm value selection :

To enter in edit mode, Press SET & RESET key simultaneously for >=2 sec. Product firmware version is displayed for approx. 800ms and then password

To set alarm value Press SET key to select each digit & press RESET key to edit the digit, Press SET key. The next digit starts blinking, after modifying last digit all digits starts blinking.

Press SET to set the Alarm time. Refer Scr 8 to Scr 10

Note: Alarm is of recurring type alert. Recurring alert occurs continuously at a pre-defined period. It is Start to Start type.

After changing Alarm value, if new Alarm value less than Current value then, output will turn on at display value equal to (Current value + alarm value). If new alarm value is greater than current display value, then output turns when alarm value is reached. Alarm output dependancy :

Alarm output dependancy: This is the dependancy of offset output with alarm output. If R_{LOPd} \exists is selected then, Offset output is acknowledged before turning ON the alarm output, then alarm output will not turn ON when alarm value is reached.

If RLoPd n is selected then alarm output will turn ON at alarm value reached.

Refer Scr 14 to Scr 15

Offset value selection: User can select offset output with Alarm output

Offset value should not be greater than or equal to Alarm value. While editing the offset value, care has been taken to avoid the selection of such value. i.e. If offset value is greater than or equal to Alarm value then it will not accept. Refer Scr 11 to Scr 13

Output Enable/Disable : Using this setting output can be made either enabled or disabled.

When output is **Enable** then the output will activate and alarm symbol will blink. Output Enable: $o^p - no$ and $o^p - nc$ applicable for output enable.

If select $_0P$ - $_{00}$ it turns 'ON' output when activated & 'OFF' when deactivated. If select $_0P$ - $_{00}$ it turns 'OFF' output when activated & 'ON' when deactivated.

When output is **Disable** then the output will be OFF and alarm symbol will blink.

When output is enabled, MOSFET or Relay output turns ON when alarm value is reached. When output is disabled, MOSFET or Relay output remains OFF even when alarm value is reached. Alarm symbol blinks when alarm value reaches, irrespective of output enabled/disabled

Reset Enable/Disable: Device can be reset through 4 different ways Reset Disable - Device will set as non-resettable. Refer Scr 20 to Scr 29.

● Auto reset allows user to reset Time or Count Automatically if Rtr5t - 4. Auto reset is enable, if Alarm value is enable.

For Counter:- If output type is Latch, then device will reset after acknowledged. If output type is time out, then device will reset after time out.

For Hour meter:- Device will reset hour meter after acknowledged.

- Front reset allows user to reset Time or Count by pressing RST key for 2 sec
- Terminal reset allows user to reset Time or Count by shorting reset terminal to ground for
- Power ON reset: PorSt n Count / time retains at power ON. PorSt y Count / time resets at power ON

Contrast control:

Using this function contrast level of LCD can be adjusted from 0 to 7. Refer Scr 30 $\&\,$ Scr 31


Password change:


Password is required for editing the parameter. User can set password value in between 01 to 99 00 – Password Disabled, 01- 99 – Password Enabled, **72 - Master Password.**

Save :Confirmation to save edited parameter. Refer Scr 33 to Scr 34. Save Y - Saves the edited parameter in memory.

Save N - It will not save edited parameter.

NOTE: Edit Mode timeout time: 45 sec.





Input signal selection:

Note: This part is applicable for AC-DC product only. Refer Scr 35 & Scr 36.

riodE de for DC signal selection. riodE RE for AC signal selection.

59Pon-n - There is no increment in count if signal is present at power ON.

59Ppn-Y - Increments the count if signal is present at each power ON. Refer Scr 37 & Scr 38.

Decimal point selection:-

Four decimal point position selection available. Refer Scr 39 to Scr 42.

Prescaler:-It means number of pulses required to increment display value by 1.

User has to select Decimal point position(Resolution) as per prescaler value set.

e.g. Lets say if application is of bottle counting & 10 bottles per box. So select Prescaler as 10, Set decimal point as 1, then after 10 pulses, it increments display value by 1 and for one pulse, it increments display by 0.1.

If the same application is considered as 125 bottles per box, then select prescaler as 125, Set decimal point as 3, then after 125 pulses it increments display value by 1 and for one pulse, it increments display by 0.008. Refer Scr 43

Alarm value selection :-

Refer Scr 44 to Scr 48.

Up counter functionality is recurring alarm type, output turns on every time after alarm value reaches & it continues the counting.

Down counter functionality is Preset type. It starts from alarm value & when value reaches to zero output turns on. Auto reset is not applicable for Down counter.

After changing Alarm value, if new Alarm value less than Current value then, out put turns on at display value equal to (Current value + alarm value). If new alarm value is greater than current display value then, output turns on at alarm value.

Output Enable / Disable : Using this setting output can be made either enabled Or disabled. Refer Scr 49 to Scr 52.

Output Type :- There are two type of output functionality. Refer Scr 53 to Scr 55.

Once Alarm Value reaches, Output becomes ON & remains ON until it gets acknowledged. It also retains its state after power OFF/ON cycle.

When output turns ON it remains ON till the timeout period, which is in seconds. Timeout value can be set from 1 to 9999 After this screen for Reset types, Contrast & setting same Screen 20 to 34 will

appear in order.

In counter for 1,2,3 decimal point, when display value is greater than 7 digit, then device will show "ral Dur". If device shows rollover then select the lower decimal point position. In No decimal point - after rollover value will reset to zero.

DIGITAL HOUR METER

Cat. No.: Z1222N0G0FT00




FEATURES:

- Suitable for Hour meter application
- Retentive mode.
- 7 Digit LCD with luxurious green backlight.
- Compact size.
- Suitable for panel mounting.

CONNECTION DIAGRAM:


For Z1222N0G0FT00




Description	Terminal
Supply	1(L/+ve),2(N/-ve)
+ve for signal	4(L/+ve)
-ve for signal	3(N/-ve)
Terminal Reset	Short 5 - 6
No Connection (NC)	7,8

NC: No Connection

Proximity Switch Connection Diagram:



Overall Product Dimensions & Mounting Details (in mm)



SYMBOL MEANING:

S	ymbol	Meaning
	X	Hourmeter - Blinking symbol means signal present.

TERMINAL DETAILS:

Ø3.5 mm	0.40 N. m (3.5 Lb.in)	
	1X 2.5 mm² Solid Wire	
AWG	22 to 14	

Panel cutout 22.0 mm X 44.8 mm

Supply Characteristics :				
Supply Voltage Range (Un)		85 to 265 VAC/VDC		
Power Consumption	1	2VA / 1W		
Supply Frequency		50/60 Hz		
T/P Signal Ch	naracteristics :			
Signal Voltage Ra		85 to 265 VAC & 100 to 265 VDC		
Signal Isolation	90	2KV		
	ataviation .	ZNV		
Output Chara	icteristics :			
Output type		NA		
Functional Ch	naracteristics:			
Display		7 digit LCD , 6.5 mm Height, 12 O' Clock, Transmissive		
Reset function	Reset type	Terminal		
Reset function	Time(min.)	80 ms		
Accuracy	1,	+/- 2 Sec per day		
,				
Range		Hrs : Min (99999:59)		
Input Signal		Refer Note2		
	tal Characteristic	cs:		
Operating Temper	rature	-5° C to +55° C		
Storage Tempera	ture	-10° C to +60° C		
Humidity		95% Rh (Without condensation)		
Maximum Operat	ing Altitude	2000 m		
Pollution Degree		II		
Degree of Protect		Front side: IP40; Terminals: IP20, Housing: IP30		
Enclosure materia	al	UL 94 V0 Plastic		
Casing color		Black		
Other Chara	cteristics :			
Mounting		Flush mounting on panel cut-out		
Panel Cut-out		22mm X 44.8mm		
Weight (Un-packe		52 gm		
Operating Position		Horizontal		
Termination wire		Wire size: 22-14 AWG, 0.3-2.5 mm		
EMI/EMC Co	ompliance:			
Harmonic Current		IEC 61000-3-2 Class A		
Voltage Flicker &	Fluctuation	IEC 61000-3-3 Class A		
ESD	1.10	IEC 61000-4-2 Level II		
Radiated Suscepti	bility	IEC 61000-4-3 Level III Criteria B		
Electrical Fast Tra		IEC 61000-4-4 Level IV		
Electrical Fast Tra	nsients(Signal)	IEC 61000-4-4 Level III		
Surge	111 110	IEC 61000-4-5 Level III		
Conducted Susce		IEC 61000-4-6 Level III		
Power Frequency	Magnetic Field	IEC 61000-4-8 Class 4		
Voltage Dips		IEC 61000-4-29 Class B		
Conducted Emissi		CISPR 14-1 Class A		
Radiated Emission		CISPR 14-1 Class A		
Safety Comp		15C C0047 5 1 2 5 107		
Test Voltage (All terminal to housing)		IEC 60947-5-1 2.5 kV		
Single fault		IEC 61010-1		
Leakage Current		UL 508 <3.5 mA		
	tal Compliance :			
Cold Heat		IEC 60068-2-1		
Dry Heat		IEC 60068-2-2		
Vibration		IEC 60068-2-6 5 g		
Repetitive Shock		IEC 60068-2-27 40 g, 6 ms		
Non-repetitive Shock		IEC 60068-2-27 30 g, 15 ms		
NOTF:				

Z1222N0G0FT00

NOTE

Product Catalog Number

1. Product firmware version is displayed for 500ms and then Screen 1 is displayed and counting will start.

00:0000

- 2. For Hour counting detection, Signal has be present for min. 3msec and signal has be absent for min 20msec.
- e.g. a. If the signal has 5 msec ON & 30 msec OFF, 5 msec time will keep on accumulating for every pulse. 30 msec off period will be considered as zero.
 - b. If signal has 3 msec ON time & 17 msec off time, then this full period (3+17=20 msec) will be treated as signal present and time will be calculated for full period of signal presence.
- 3.Terminal reset allows user to reset Time by shorting reset terminal to ground for minimum 80 mS.
- 4. In hourmeter for 1,2,3 decimal point, when display value is greater than 7 digit(>99999:59), then device will show "Rollover". If device shows rollover then short 5 & 6 to make all count reset. Since, product is having retentive feature count will not reset automatically.



5. **Optional Accessory:** ZF1907P: This is the Adapter plate suitable for mounting the Digital Hour meter, in panel cutout of 50mm x 25mm with counter sunk M4 screw fitting with vertical center to center distance of 38,2mm.

Caution

- 1. Always follow the instructions stated in this product leaflet.
- 2. Before installation, check to ensure that the specifications agree with the intended application.
- 3. Installation to be done by skilled electrician.
- 4. Automation & Control devices must be properly installed so that they are protected against any risk of involuntary actuations.
- 5. Suitable dampers should be provided in case of excessive vibrations
- 5. Use of 150 mA fuse in series with product supply is recommended, for protection.
- Product innovation being a continuous process, we reserve right to alter any specifications without prior notice.

Following devices are also available in scope of GIC P. Ltd, Z2221N0G2FT00 - DCHM, 80-265 VAC/DC, RELAY OUTPUT Z2301N0G1FT00 - DCHM, 9-30 VDC, 2 MOSFET OUTPUT For more details please visit us www.gicindia.com